


# éleino

## Mini folding fan user's manual



Dear buyer,  
Thank you very much for using this ELEINO mini folding fan. Please read this manual carefully before using and use it properly to get the best performance of the product. This fan's folded storage can save space, so you can use it at home, outside and at the office to enjoy cool anytime, anywhere, without plugging it thanks to his great battery. You can also program it when you go to sleep. You will love it !

Please keep the instruction manual and its product accessories in order to enjoy better service.

### Products parameters:

Name:	ELEINO mini folding fan	Working time:	Between 5 - 24 hours (depending on wind speed)
Model:	ELEINO M1	Charging time:	About 5 hours
Material:	Aluminum alloy & ABS plastic	Discharge power:	1.3 ~ 4.8W
Battery model:	Lithium battery 18650	Charging current:	2A
Cell model:	3.7V 7200mAh	Charging voltage:	DC5V
Noise decibel:	About 30 – 40 db	Working wind speed:	2.3 ~ 4.0m / s
Product size:	20,5 * 20,5 * 10,2cm (folded) 20,5 * 20,5 * 102cm (stretched)		

### Accessories:

The fan contains the following accessories.



Host



Remote control



Charging cable




Manual

### Function keys and description:

- Gear indicator: There are 4 gears for the fan, 1 for gentle wind, 2 for medium wind, 3 for strong wind, 4 for natural wind, and 4 indicators for 4 gears
- Battery indicator: When the fan is used and turned off, the battery indicator will light up. The four lamps (color is white) correspond to about 25% / 50% / 75% / 100% of the power in sequence. Approximately fully charged. When the fan is charging, the power indicator lights will turn on one by one, and depending on the battery's current power situation, all four lights will light up to indicate that the battery is fully charged. Short press the power button of the remote control to check the power; long press the power button of the host for 2 seconds to check the power.
- Fan switch: When the fan is off, turn on the fan switch in order of 1.2.3.4, 1st for gentle wind, 2nd for medium wind, 3rd for strong wind, 4th for natural wind, press the switch again in 4th state The fan is turned off and cycled in turn. In any gear, press and hold the fan switch for two seconds to turn it off
- Timing switch and indicator: When the fan is on, turn on the timing switch, and you can set the corresponding time according to your needs. The corresponding timing indicator will light up (such as timing for 4 hours, the timing indicators will all light up), and cycle. When the timer function is on, the timer indicator lights up to indicate the remaining time of the timer (if two timer lamps are on, it means that the fan will turn off after about 1 to 2 hours).
- Type-c charging port: This charging port is an international universal type-c interface with a standard input voltage of 5v. Do not use other types of charging cables to charge the fan.
- Mobile power function: This fan has a mobile power function, which can be used for emergency charging of mobile phones and other electronic equipment. The discharge current is about 2A.

**Product icon:**



**After-sales service description:**

**Warranty period**  
 The warranty period of this product is valid for 12 months from the date of purchase.

**Free service**  
 During the product warranty period, for any failure caused by the quality of the product, please contact ELEINO or TN2M DISTRIBUTION customer service with this voucher to enjoy free warranty service.

- The following conditions are not free of charge:
1. Damaged product label;
  2. Failure to use according to the instructions or damage caused by using non-original accessories
  3. Disassembly, repair and damage caused by yourself;
  4. Malfunction caused by water ingress or fall, and man-made mechanical damage;
  5. Malfunction or damage caused by force majeure;
  6. Counterfeit and shoddy products purchased through informal channels.

After your purchase, you have 15 days to change your mind. If so, you must send this information by email to [contact@tn2m-distribution.com](mailto:contact@tn2m-distribution.com). Please note that the shipping cost to send back the product are not included.

**Precautions:**

- a. Please use the machine as instructed in the manual, otherwise accidents such as fire or electric shock may occur;
- b. Do not place the product on a high place and on an uneven table or floor to prevent the product from falling and being damaged;
- c. When using the remote-control function, the distance from the host is about 2.5 meters, and point at the receiving head of the host;
- d. Do not use a power supply that exceeds the load of the product, which will cause the product to heat up and damage the circuit board;
- e. This fan battery is built-in and cannot be removed. Do not disassemble the battery at will to avoid danger;
- f. When the fan is running, do not insert fingers, pencils, hard objects, or any other slender objects into the machine through the net cover;
- g. Do not bump or throw this product, so as not to cause internal failure of the product;
- h. Do not expose this product to rain or humid environment;
- i. Do not disassemble, repair and modify this product by yourself;
- j. Unauthorized disassembly will invalidate the warranty;

**Warranty Card:**

Problem found or reason: \_\_\_\_\_  
 \_\_\_\_\_  
 Product number: \_\_\_\_\_  
 Date of purchase: \_\_\_\_\_  
 Invoice number: \_\_\_\_\_  
 Name: \_\_\_\_\_  
 Telephone: \_\_\_\_\_  
 Email: \_\_\_\_\_  
 Postal code & city: \_\_\_\_\_

**Warning: This product is not suitable for children 6 years of age and younger to operate alone. The explanation right of this manual belongs to our company.**